

## **U-BRACKETS**

ONE SYSTEMS offers a variety of U-Brackets. Each bracket is optimized for a particular ONE SYSTEMS loudspeaker enclosure. The enclosures with corresponding U-Brackets are as follows:

Loudspeaker	U-Bracket
104HTH	104HTH-U/M
106HTH	106HTH-U/M
108HTC	108HTC-U/M
108HTH	108HTH-U/M
208HTC	108HTH-U/M
112HTH	112HTH-U/M
118HSB	118HSB-U/M
212HC	112HTH-U/M
312HC	312HC-U/M
CFA-HTH	CFA-HTH-U/M



Caution should be exercised when connecting stainless steel to non stainless steel (dissimilar metal) structures in ocean front and general marine environments. Compatible fastening hardware and other metals must be used. Appropriate anode to cathode area ratios must also be maintained in ocean front and marine environments. A structural engineer with galvanic corrosion experience should be consulted prior to installation of any products in ocean front or general marine environments.

The One Systems U-Bracket installation manual can be found on the One Systems web site under the home page Documentation Tab, followed by Technical Papers, and the to the U-Bracket installation manual hyperlink: http://onesystems.com/pdf/educations/U Bracket Installation.pdf

Please note from the chart above that several U-Brackets are used on multiple enclosures. DO NOT SUBSTITUTE BRACKETS, OR USE OTHER LOUDSPEAKER SYSTEMS THAN AS LISTED ABOVE!



Ø

0


0



## **U-BRACKETS**

It is necessary that the installation and application of all suspended products conform to local and national codes. Installation of U-Brackets should only be attempted by an experienced professional who is familiar with local and national codes, as well as and safe suspension practices. ONE SYSTEMS requires that the document "Rigging and Suspension of ONE SYSTEMS Products" be read and completely understood. This document is also available at www.onesystems.com under the Documents and Technical Papers sections.

All U-Bracket dimensions and drawings may be found in the Accessories section of the One Systems web site home page, or may be requested directly from One Systems by calling +1-615-823-1655, or by calling 1-866-846-1284 toll free in North America, or by writing to info@oneystems.com.



Other One Systems U-Bracket CAD drawings can be found on the One Systems website under the Accessories section, in the Documents area, as well as the appropriate U-Bracket with corresponding loudspeaker system.



One Systems, Inc • Nashville, TN One Systems Global Co. Ltd. • 399/1 Srinakarin Road • Huamak, Bangkapi Bangkok, Thailand 10240